

# Applying an Impregnator to a Wall or Vertical Surface

---

## Applying an Impregnator to a Wall or Vertical Surface

It can be challenging to apply an impregnator to a natural stone wall or vertical surface, because gravity causes the product to drip and dribble before it has time to be absorbed. It is no surprise that contractors often end up with uneven coverage and wasted product.

Fred Hueston, Chief Technical Director of Surface Care Pros and owner of [Stone Forensics](#) provides the following recommendations for applying impregnator to a wall or vertical surface that has a polished finish:

- Use a roller, cloth, or lambs wool applicator.
- Thoroughly saturate the applicator in sealer.
- Apply the product to the wall from the bottom up.
- Continue to apply, making sure to thoroughly saturate the surface.
- Several applications may be necessary.
- To prevent streaking, clean excess sealer off the wall by wiping with a dry cloth.

Hueston recommends using a sprayer to apply impregnator to a wall or vertical surface that has an unpolished finish. He warns, “The solvents in the impregnators can be damaging to the sprayer parts. Use a solvent-resistant sprayer.”

## Learn More

For more information, register to earn a [Stone Restoration Master Course Certificate](#). You'll learn how to restore natural stone floors, countertops, and walls, engineered stone, and granite floors, using the most efficient and

effective restoration procedures. Also included in this program is the Stain Care Pro course with a one-year subscription to the Stain Care Pro app and Understanding Sealers.

Online URL:

<https://surfacecarepros.com/kb/article/applying-an-impregnator-to-a-wall-or-vertical-surface-879.html>